



1
Unfold PMLL Handle to 90 Degrees



2
Uncover Magnet and Position
Onto Transformer Lid.



- 3) Rotate Outer Handle Counter-Clockwise;
4) Pull Outer Handle to Extend;
5) Rotate Outer Handle Clockwise to Lock in Place



*For difficult transformers
to open – use the handle
in the non-extended
position (See #3)*



With PMLL Secured and Lower Lip Engaged , Lift Safely!
To disengage magnet, see next page.

To disengage magnet from transformer lid, rotate handle downward.



Rotate tool body until pivot point contacts transformer lid.



With handle parallel to transformer lid, magnet will disengage.